

HONDA CR-V

Axeltätningar/Shaft seals

Art.#/part#

97-01 SD TRS090 FS24048

Exp.ventiler/Exp.valves

Art.#/part#

97-01 FS39000
02-06 FS39006

Kompressorer/Compressors

Art.#/part#

97-01 SD TRS090 FS78560
02-06 HS110R FS58881
2007- 2,0 lit SD TRS FS58915-6
2009- 2,4 lit SD TRSE090A FS98580

Kondensorer/Condensers

Art.#/part#

97-01 RN39804
02-06 RN40268
2007- RN40562

Kylelement/Evaporators

Art.#/part#

97-01 FS54296
02-05 FS54898

Lager/Clutch bearings

Art.#/part#

97-01 SD TRS FS25900-1

Packningssatser/Gasket kits

Art.#/part#

Slangheter/Hose asy.

Art.#/part#

Torkfilter/Driers

Art.#/part#

97-01 FS33595
02-04 FS83019

Tryckvakter/Press.switches

Art.#/part#

HONDA CR-V

Axeltätningar/Shaft seals



Art# FS24048

Exp.ventiler/Exp.valves




Art# FS39000
Org# 80220ST7A12



Art# FS39006
Org# 80220S5AG02

Kompressorer/Compressors




Art# FS78560
Org# 38810P2FA01




Art# FS58881
Org#

Kondensorer/Condensers




Art# RN39804
Org# 80110S10003



Art# RN40268
Org# 80101SCAA01

Kylelement/Evaporators



Art# FS54296
Org# 80215ST3G11



Art# FS54898
Org# 80215S5DA01

Packningssatser/Gasket kits

Torkfilter/Driers



Art# FS33595
Org# 80351501A01



Art# FS83019
Org# 80101S9A013

Tryckvakter/Press.switches