

# HONDA FR-V

<b>Axeltätningar/Shaft seals</b>	Art.#/part#	<b>Packningssatser/Gasket kits</b>	Art.#/part#
2005- SD TRS090	FS24048		
<b>Exp.ventiler/Exp.valves</b>	Art.#/part#	<b>Slangheter/Hose asy.</b>	Art.#/part#
2005-	FS39006		
<b>Kompressorer/Compressors</b>	Art.#/part#		
2005- 1,7/1,8/2,0 lit SD TRS090	FS78599		
		<b>Torkfilter/Driers</b>	Art.#/part#
		2005-	FS83132
<b>Kondensorer/Condensers</b>	Art.#/part#		
2005- 1,8/2,0 lit	RN10915-4		
		<b>Tryckvakter/Press.switches</b>	Art.#/part#
<b>Kylelement/Evaporators</b>	Art.#/part#		
<b>Lager/Clutch bearings</b>	Art.#/part#		
97-01 SD TRS	FS25900-1		