

HYUNDAI SONATA

Axeltätningar/Shaft seals Art.#/part#
94-98 FS10 FS24032-1

Exp.ventiler/Exp.valves Art.#/part#
94-98 FS38639

Kompressorer/Compressors Art.#/part#
94-98 4-Cyl FS10 FS58154

Kondensorer/Condensers Art.#/part#
94-98 RN11013

Kylelement/Evaporators Art.#/part#
94-98 FS54904-2

Lager/Clutch bearings Art.#/part#
94-98 FS10 FS25204

Packningssatser/Gasket kits Art.#/part#


Slangheter/Hose asy. Art.#/part#

Torkfilter/Driers Art.#/part#
92-94 4-Cyl FS33910-1
92-93 6-Cyl FS33910-2
1994 6-Cyl FS33910-3
95-98 4/6-Cyl FS33910-4

Tryckvakter/Press.switches Art.#/part#

HYUNDAI SONATA

Axeltätningar/Shaft seals



Art# FS24032-1


Exp.ventiler/Exp.valves



Art# FS38639

Org#


Kompressorer/Compressors



Art# FS58154

Org# 97701-34001

Kondensorer/Condensers



Art# RN11013

Org# 97606-34003

Kylelement/Evaporators



Art# FS54904-2

Org# 97601-24001

Packningssatser/Gasket kits


Slangheter/Hose asy.

Torkfilter/Driers




Art# FS33910-1

Org# 97820-33300




Art# FS33910-2

Org# 97820-33370



Art# FS33910-3

Org# 97820-33381



Art# FS33910-4

Org# 97820-34001

Tryckvakter/Press.switches