

# NISSAN TERRANO II


<b>Axeltätningar/Shaft seals</b>	Art.#/part#	<b>Magnetkopplingar/Clutches</b>	Art.#/part#
<b>Exp.ventiler/Exp.valves</b>	Art.#/part#		
93-97	FS38637	<b>Packningssatser/Gasket kits</b>	Art.#/part#
<b>Kompressorer/Compressors</b>	Art.#/part#		
		<b>Slangheter/Hose asy.</b>	Art.#/part#
<b>Kondensorer/Condensers</b>	Art.#/part#	<b>Torkfilter/Driers</b>	Art.#/part#
93-97 R20	RN18242	93-97 R20	FS33590
1998-	RN18242-1	98-01	FS33921-0
<b>Kylelement/Evaporators</b>	Art.#/part#	<b>Tryckvakter/Press.switches</b>	Art.#/part#
<b>Lager/Clutch bearings</b>	Art.#/part#		

# NISSAN TERRANO II

## Axeltätningar/Shaft seals

## Kylelement/Evaporators

## Exp.ventiler/Exp.valves



Art# FS38637  
Org# 922007E100

## Packningssatser/Gasket kits

## Kompressorer/Compressors

## Torkfilter/Driers




Art# FS33590  
Org#




Art# FS33921-0  
Org# 921319F500

## Kondensorer/Condensers



Art# RN18242  
Org# 9211070P00



Art# RN18242-1  
Org# 921100F010

## Tryckvakter/Press.switches