

# SEAT TOLEDO

<b>Axeltätningar/Shaft seals</b>	Art.#/part#	<b>Magnetkopplingar/Clutches</b>	Art.#/part#
94-04 SD7V16	FS24043		
<b>Exp.ventiler/Exp.valves</b>	Art.#/part#	<b>Packningssatser/Gasket kits</b>	Art.#/part#
94-04	FS38670	94-04 SD7V16	FS24902-0
<b>Kompressorer/Compressors</b>	Art.#/part#	<b>Slangheter/Hose asy.</b>	Art.#/part#
94-98 Alla / All	FS57905-0		
99-04 Alla / All	FS5801206		
<b>Kondensorer/Condensers</b>	Art.#/part#	<b>Torkfilter/Driers</b>	Art.#/part#
94-96 Alla / All	RN10914-0	91-93	FS33364
97-98 Alla / All	RN10914-1	94-98	FS33905-1
99-04 Alla / All	RN10908-0	99-04	FS33978
<b>Kylelement/Evaporators</b>	Art.#/part#	<b>Tryckvakter/Press.switches</b>	Art.#/part#
99-04	FS54907-1	94-04 Trinary switch	FS36904-0
<b>Lager/Clutch bearings</b>	Art.#/part#		
94-04 SD7V16	FS25212		

# SEAT TOLEDO

## Axeltätningar/Shaft seals



Art# FS24043

## Exp.ventiler/Exp.valves




Art# FS38670  
Org# 1H0820679A

## Kompressorer/Compressors




Art# FS57905-0  
Org# 7M0820803D




Art# FS5801206  
Org# 1L0820413B


## Kondensorer/Condensers



Art# RN10908-0  
Org# 1J0820413B



Art# RN10914-0  
Org# 1L0820413B




Art# RN10914-1  
Org# 1L0820413D

## Kylelement/Evaporators

Ingen bild


Art# FS54907-1  
Org#

## Packningssatser/Gasket kits



Art# FS24902-0

## Torkfilter/Driers



Art# FS33364  
Org# 176820191



Art# FS33905-1  
Org# 1L0820191



Art# FS33978  
Org# 1J820191D

## Tryckvakter/Press.switches



Art# FS36904-0  
Org# 6K0959139